-5°/+5°

4. Place the TV/ display on the wall mount

**5.** Adjust the angle and lock the mount

LOGIC

INSTALLATION MANUAL

SWIVEL WALL MOUNT

View after installing the mount on the wall

MODEL	SERIES	VESA	DISPLAY SIZE	MAX LOAD
LGWM-5586SW	SWIVEL MOUNT	100x100 to 600x400	55" to 86"	110 lbs (50 kg)

Hardware

M SERIES

M-A QTY : 4	M-B QTY : 4	M-C QTY : 4	M-D QTY : 4	M-E QTY : 4	M-F QTY : 4
M6 WASHER	M8 WASHER	M6 X 25	M8 X 25	SMALL BUSH	BIG BUSH

W SERIES

W-A QTY : 6	W-B QTY : 6	W-C QTY : 6
EXPANSION PLUG	CONCRETE SCREW	WASHER

Checklist

Swivel wall mount bracket X 1
Interface bracket X2

W-A	W-B	W-C

W Series Pouch

M-A	M-B	M-C	M-D	M-E

M Series Pouch

IMPORTANT : Prior to installation, ensure that you have received all the parts as per the checklist

1. Product Dimension

360 MM

200 MM

MIN 85 - MAX 371 MM

VESA MIN 100 - MAX 400

162 MM

VESA MIN100-MAX600

644 MM

-5°/+5°

Dimension in mm

2. Installation

Instructions for fixing wall mount:

ATTENTION: Drilling the wall for the wall mount should be executed by a craftsperson only. Exercise care to prevent any scar or damage to the wall.

CAUTION : Wear safety glasses while operating power equipment. Failure to comply may result in eye injury

W-B
W-C
W-A

1. Place the wall unit on the wall and make marks on the wall.
   Note: While marking make sure the mount is placed in a straight line using the surface leveler Drill the wall and insert the concrete anchor in the holes & place the mount on the wall and insert concrete screws. (Refer W-A, W-B, and W-C, in the checklist)

M-C OR M-D
M-A OR M-B
M-E OR M-F

2. Place the interface bracket on the TV/ display and insert the washer and screw (Refer the checklist for the suitable screw and washer)

3. For a curved back or obstruction in display or TV kindly follow the above process